

CONNECTOR, Chev/GM Vehicle Specific

INSTALLATION INSTRUCTIONS

WARNING: The attachment and installation of this product is beyond the control of Winston Products, LLC. Winston Products, LLC is not responsible for the attachment or the installation of this product. Winston Products, LLC is not liable for damages and/or injuries that are the result of improper use/attachment or are the result of use beyond the intended towing application. The liability of this product is limited to the purchase price if it proves to be defective in material and/or workmanship. Any and all warranties, explicit or implied, are void if the product is damaged or worn.

- 1. Locate the vehicle tow package harness directly behind the rear bumper or inside the driver's side frame channel. This harness should have the same connector ends as the TowSmart vehicle specific harness.
- 2. Disconnect the vehicle tow package harness, being careful not to break the locking tabs.
- 3. Apply a small amount of dielectric grease to all electrical connectors to help prevent corrosion.
- 4. Plug the TowSmart vehicle specific harness into the male and female disconnected harness. Ensure the connectors are fully inserted with the locking tabs firmly in place.
- 5. Locate a grounding area on the vehicle frame and remove any dirt or rust. Ground the white wire to the frame with a self-tapping screw.

APPLICATIONS:

CADILLAC		CHEVROLET		GMC	
Escalade	1999 - 2000	Blazer (Full Size)	1992 - 1994	Denali	1999 - 2000
		Pickup (Full Size)	1988 - 1998	Jimmy (Full Size)	1992 - 1994
		Pickup C/K	1999 - 2000	Pickup (Full Size)	1988 - 1998
		Suburban	1992 - 1999	Pickup (Full Size)	1999 - 2000
		Tahoe	1995 - 2000	Suburban	1992 - 1999
				Yukon	1992 - 1999

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR TOWSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9215 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT WWW.TOWSMART.COM.

