

EXTENSION, 4-Flat to 4-Flat, 12 IN

INSTALLATION INSTRUCTIONS

WARNING: The attachment and installation of this product is beyond the control of Winston Products, LLC. Winston Products, LLC is not responsible for the attachment or the installation of this product. Winston Products, LLC is not liable for damages and/or injuries that are the result of improper use/attachment or are the result of use beyond the intended towing application. The liability of this product is limited to the purchase price if it proves to be defective in material and/or workmanship. Any and all warranties, explicit or implied, are void if the product is damaged or worn.

WIRE IDENTIFICATION:

Ground = White Taillight = Brown Left Turn/Brake = Yellow Right Turn/Brake = Green

- 1. Apply dielectric grease to all terminals to help prevent corrosion.
- 2. Attach the trailer side 4-flat of the extension to the trailer tow harness 4-flat connector.
- 3. Attach trailer coupler to the hitch ball on the tow vehicle. Plug the completed extension into the tow vehicle and test all functions.

NOTES:

Locate wires and pin location by function on tow vehicle or trailer. Color coding is not standard among manufacturers.

Dielectric grease applied to the terminals on a regular basis will assist in preventing corrosion.

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR TOWSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9215 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT WWW.TOWSMART.COM.

