

BRAKE CONTROL CONNECTOR (Ford, Lincoln, Mercury, Land Rover)

INSTALLATION INSTRUCTIONS

⚠ WARNING: The attachment and installation of this product is beyond the control of Winston Products, LLC. Winston Products, LLC is not responsible for the attachment or the installation of this product. Winston Products, LLC is not liable for damages and/or injuries that are the result of improper use/attachment or are the result of use beyond the intended towing application. The liability of this product is limited to the purchase price if it proves to be defective in material and/or workmanship. Any and all warranties, explicit or implied, are void if the product is damaged or worn.

1. Locate the vehicle connector under the dash below the steering wheel.
2. Plug the mating end of the brake control connector into the vehicle connector.
3. Plug the other end into the brake control of choice.
4. Test all functions for performance.
5. Cable tie or secure any loose wires under dash.

FITS VEHICLES	
Ford	
Bronco	1994 - 1996
Econoline Van	1992 - 2008
Excursion	2000 - 2005
Expedition	1997 - 2012
Explorer	2001 - 2020
F-150	1994 - 2008
F-250 / F-350	1994 - 2004
F-53 Motor Home Chasis	2000 - 2014
Flex	2006 - 2011
Windstar	1995 - 2003
Land Rover	
LR3	2005 - 2009
LR4	2010 - 2016
Range Rover	2010 - 2017
Range Rover Evoque	2012 - 2016
Range Rover HSE	2005 - 2009
Range Rover HSE	2016 - 2016
Lincoln	
Mark LT	2007 - 2008
MKT	2010 - 2011
Navigator	1998 - 2012
Mercury	
Mountaineer	2000 - 2011

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR TOWSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9215 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT WWW.TOWSMART.COM.



A Winston Products Company
 TOWSMART.COM
 WINSTON PRODUCTS, LLC.
 30339 Diamond Parkway
 Cleveland, OH 44139